WEILAND

DOOR PANEL TRAVEL SPEED ADJUSTMENT

- [ ] 1 Use the **DOWN** button until the screen reads SYSTEM CONFIG.
- [ ] 2 Press **ENTER** once.
- [ ] 3 Use the **DOWN** button until the **FREQUENCY** is highlighted.
- [ ] 4 Press **ENTER** once.
- [ ] 5 Enter password **413**.
- [ ] 6 Press **ENTER** once.
- [ ] 7 Use the **DOWN** button until **OPEN** or **CLOSE** is highlighted.
  (Do not adjust pre open or pre close these auto adjust)
- [ ] 8 Press **ENTER** once.
- [ ] 9 Change this value to effect speed .
- [ ] 10 Press **ENTER** once.
- [ ] 11 Hold **Enter** until back to main screen
- [ ] 12 The open frequency may need to be adjusted or lowered a couple times until the door runs at desired speed.

© 2025 Weiland Doors. All rights reserved.
For the most up-to-date product information, visit www.weilanddoors.com.

806 W. S. Airport Road, Norfolk, NE 68701
402-454-2106
info@weilanddoors.com
www.weilanddoors.com