WEILAND

HORIZONTAL SLIDER

OPERATION & MAINTENANCE SCHEDULE

Our doors are designed to offer many years of reliable, trouble-free operation with minimal maintenance, provided they are installed by qualified cold storage door installers. Installation must follow the guidelines outlined in the provided manual, and the doors should remain undamaged and unaltered except as specified by a factory-authorized representative. Additionally, the doors should be checked periodically according to the schedule below.

COOLER AND FREEZER DOORS (MANUAL/ ELECTRIC):

DAILY:

1. Smooth Operation
2. Positive Seal
3. Damage
4. Loose, Damaged or Missing Parts

WEEKLY:

1. Gaskets for tears, rips or any other damage

MONTHLY:

1. Bottom door guides, stay rollers, trolleys and wheel assemblies for proper adjustment and operation.
2. All Fasteners

© 2025 Weiland Doors. All rights reserved.
For the most up-to-date product information, visit www.weilanddoors.com.

806 W. S. Airport Road, Norfolk, NE 68701
402-454-2106
info@weilanddoors.com
www.weilanddoors.com

FREEZER DOORS (MANUAL/ ELECTRIC)

DAILY:

1. Heater for proper operation (should have uninterrupted and separate power supply).

ELECTRIC DOORS

DAILY:

1. Reversing edge for proper operation
2. Pull switches for proper operation

MONTHLY:

1. Drive chain tension and lubrication

Please make any and all adjustments to ensure smooth operation and positive seal as required per installation instructions provided with each door. Repair and/or replace any worn, damaged or defective part as soon as detected.

© 2025 Weiland Doors. All rights reserved.
For the most up-to-date product information, visit www.weilanddoors.com.

806 W. S. Airport Road, Norfolk, NE 68701
402-454-2106
info@weilanddoors.com
www.weilanddoors.com