WEILAND

Weiland Powered Bi-Part Slider

DE-ACTIVATING PHOTO EYE SENSORS

- [ ] 1 Open main controller box (the one with the open/close buttons) by unscrewing the four corner screws
- [ ] 2 Press **Menu/Enter** button to enter Menus screen
- [ ] 3 Use the **Down** ↓ button to scroll down the menu selections
- [ ] 4 Find the System Config menu
- [ ] 5 Press **Menu/Enter** button to enter the System Config
- [ ] 6 The screen will display - Enter Code / Menu Locked (There is no code or code is 0)
- [ ] 7 Press **Menu/Enter** button to enter
- [ ] 8 Use the **Down** ↓ button to scroll down the menu selections
- [ ] 9 Find the Inputs menu
- [ ] 10 Press **Menu/Enter** button to enter the Inputs menu
- [ ] 11 Use the **Down** ↓ button to scroll down the menu selections
- [ ] 12 Find the Aux2
- [ ] 13 Press **Menu/Enter** button to select Aux2
- [ ] 14 Press **Menu/Enter** button to select Function (the first menu item that comes up)
- [ ] 15 Press **Up** ↑ to scroll the menu
- [ ] 16 Find No Function
- [ ] 17 Press **Menu/Enter** button to select No Function
- [ ] 18 Press and HOLD **Menu/Enter** button (do not let go) until you return to the main/home screen.

Deactivation of photo eyes is intended for testing purposes only. Weiland Doors does not assume any liability for damages, injuries or any other results that happen as a result of deactivation of factory installed safety devices.

© 2025 Weiland Doors. All rights reserved.
For the most up-to-date product information, visit www.weilanddoors.com.

806 W. S. Airport Road, Norfolk, NE 68701
402-454-2106
info@weilanddoors.com
www.weilanddoors.com